




IMPORTANT NOTICE - READ CAREFULLY
Telescoping Meter Flange

Installation Instructions

1) Keep flange extended with spacer during installation and pressurization.



2) To remove water meter, pull spacer out of groove and retract flange.

800.292.2737 | sales@aymcdonald.com | aymcdonald.com


3210-611 1/18



IMPORTANT NOTICE - READ CAREFULLY
Telescoping Meter Flange

Installation Instructions

1) Keep flange extended with spacer during installation and pressurization.



2) To remove water meter, pull spacer out of groove and retract flange.

800.292.2737 | sales@aymcdonald.com | aymcdonald.com


3210-611 1/18



IMPORTANT NOTICE - READ CAREFULLY
Telescoping Meter Flange

Installation Instructions

1) Keep flange extended with spacer during installation and pressurization.



2) To remove water meter, pull spacer out of groove and retract flange.

800.292.2737 | sales@aymcdonald.com | aymcdonald.com


3210-611 1/18



IMPORTANT NOTICE - READ CAREFULLY
Telescoping Meter Flange

Installation Instructions

1) Keep flange extended with spacer during installation and pressurization.



2) To remove water meter, pull spacer out of groove and retract flange.

800.292.2737 | sales@aymcdonald.com | aymcdonald.com


3210-611 1/18



IMPORTANT NOTICE - READ CAREFULLY
Telescoping Meter Flange

Installation Instructions

1) Keep flange extended with spacer during installation and pressurization.



2) To remove water meter, pull spacer out of groove and retract flange.

800.292.2737 | sales@aymcdonald.com | aymcdonald.com


3210-611 1/18



IMPORTANT NOTICE - READ CAREFULLY
Telescoping Meter Flange

Installation Instructions

1) Keep flange extended with spacer during installation and pressurization.



2) To remove water meter, pull spacer out of groove and retract flange.

800.292.2737 | sales@aymcdonald.com | aymcdonald.com


3210-611 1/18



IMPORTANT NOTICE - READ CAREFULLY
Telescoping Meter Flange

Installation Instructions

1) Keep flange extended with spacer during installation and pressurization.



2) To remove water meter, pull spacer out of groove and retract flange.

800.292.2737 | sales@aymcdonald.com | aymcdonald.com


3210-611 1/18



IMPORTANT NOTICE - READ CAREFULLY
Telescoping Meter Flange

Installation Instructions

1) Keep flange extended with spacer during installation and pressurization.



2) To remove water meter, pull spacer out of groove and retract flange.

800.292.2737 | sales@aymcdonald.com | aymcdonald.com


3210-611 1/18



IMPORTANT NOTICE - READ CAREFULLY
Telescoping Meter Flange

Installation Instructions

1) Keep flange extended with spacer during installation and pressurization.



2) To remove water meter, pull spacer out of groove and retract flange.

800.292.2737 | sales@aymcdonald.com | aymcdonald.com


3210-611 1/18



IMPORTANT NOTICE - READ CAREFULLY
Telescoping Meter Flange

Installation Instructions

1) Keep flange extended with spacer during installation and pressurization.



2) To remove water meter, pull spacer out of groove and retract flange.

800.292.2737 | sales@aymcdonald.com | aymcdonald.com

3210-611 1/18

